



Notes:

- Its OK to connect ground to the chassis, however use wire to connect all ground terminations (same size as +V)
- Ensure all electronics are electrically isolated from chassis
- (A) Mount Mobile Transceiver so antenna is not blocked or covered by any metal, etc.
- (B) Must Solder wires onto back of OOPic-R board to access the TTL lines of the OOPic see www.superdroidrobots.com/product_info/RF.htm
- (C) connect to 5V TTL Header
- (D) Program Header (behind serial DB9)

