



Notes:

1. The 2 bigger gauge wires are the one that connect to the motor controller (red and black), the 2 smaller gauge wires are the brakes (black).
2. The polarity in the brake wires does not matter, voltage must be 24V.
3. Before spinning the motor make sure that the brakes are released. (You can burn the motor if you not release the brake before spinning the motor).
4. Estop is not necessary, the wire can be connected directly to 24v.

