



Notes:

1. The 2 bigger gauge wires connect to the motor controller (red and black), the (2) smaller gauge wires are for the brakes.
2. The polarity in the brake wires does not matter, voltage must be 24V.
3. Before spinning the motor make sure the brakes are released. You can burn the motor if the brake is not released before spinning the motor.



SuperDroid Robots Inc

WheelChair\_Motors

PAGE

1 OF 1