

- Notes:**
1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
 2. Wire gauges depend on load and size of motors.
 3. Fuse size depends on load and size of motors.
 4. Switch should be rated for at least the same amount of current as the fuse.
 5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
 6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).

RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

RC Receiver
 Note In receiver connect:
 1. 0 v to pin 3, 6, 9 or 12.
 2. 5V to pin 2, 5, 8 or 11.

Arduino Pin Out


6	(Tx)S1
7	(Estop)S2
11	StrafeRC
12	DriveRC
13	TurnRC
46	(Front)S1
47	(Front)S2
48	(Rear)S1
49	(Rear)S2
50	MISO
51	MOSI
52	SCK
5V	
GND	

Dual Encoder Breakout Board

Sabertooth Front
 Address 128
 Dip Switches 3, 4, 5, 6 ON

Sabertooth Rear
 Address 129
 Dip Switches 3, 5, 6 ON





- Notes:**
1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
 2. Wire gauges depend on load and size of motors.
 3. Fuse size depends on load and size of motors.
 4. Switch should be rated for at least the same amount of current as the fuse.
 5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
 6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).
 7. If Battery is 12V you can connect the 2.1mm jack from the arduino to the 12V Bus.

RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

RC Receiver
 Note In receiver connect:
 1. 0 v to pin 3, 6, 9 or 12.
 2. 5V to pin 2, 5, 8 or 11.


Arduino Pin Out

2	Dir FL
3	PWM FL
4	Dir FR
5	PWM FR
6	PWM RR
7	Dir RR
8	Dir RL
9	PWM RL
11	StrafeRC
12	DriveRC
13	TurnRC
46	(Front)S1
47	(Front)S2
48	(Rear)S1
49	(Rear)S2
50	MISO
51	MOSI
52	SCK

Dual Encoder Breakout Board



SuperDroid Robots Inc



- Notes:**
1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
 2. Wire gauges depend on load and size of motors.
 3. Fuse size depends on load and size of motors.
 4. Switch should be rated for at least the same amount of current as the fuse.
 5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
 6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).
 7. If Battery is 12V you can connect the 2.1mm jack from the arduino to the 12V Bus.

RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

RC Receiver
Note In receiver connect:
1. 0 v to pin 3, 6, 9 or 12.
2. 5V to pin 2, 5, 8 or 11.


Arduino Pin Out

11	Strafe
12	DriveL
13	TurnF
16	TX2
17	RX2
18	TX1
19	RX1

RoboteQ SDC DB15 Pin Out

Connector Pin	Power	Dout	Com	RC	Ana	Dinput	Enc	Default Config
1		DOUT1						Unused
2			TxOut				Enc1A	RS232Tx
3			RxIn					RS232Rx
4				RC1	ANA1	DIN1		RC Radio1
5	GND							
6			CANL				Enc1B	
7			CANH					
8				RC2	ANA2	DIN2	Enc2A	RC Radio2
9		DOUT2						Unused
10					ANA5	DIN5		Unused
11				RC4	ANA4	DIN4		Unused
12				RC3	ANA3			Unused
13	GND						Enc2B	
14	5V OUT							
15					ANA6	DIN6		Unused






Notes:


1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
2. Wire gauges depend on load and size of motors.
3. Fuse size depends on load and size of motors.
4. Switch should be rated for at least the same amount of current as the fuse.
5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).
7. If Battery is 12V you can connect the 2.1mm jack from the arduino to the 12V Bus.

RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

RC Receiver
 Note In receiver connect:
 1. 0 v to pin 3, 6, 9 or 12.
 2. 5V to pin 2, 5, 8 or 11.






- Notes:**
1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
 2. Wire gauges depend on load and size of motors.
 3. Fuse size depends on load and size of motors.
 4. Switch should be rated for at least the same amount of current as the fuse.
 5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
 6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).
 7. If Battery is 12V you can connect the 2.1mm jack from the arduino to the 12V Bus.


RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

RC Receiver
Note In receiver connect:
1. 0 v to pin 3, 6, 9 or 12.
2. 5V to pin 2, 5, 8 or 11.

Arduino Pin Out	
FR PWM	2
FR INA	22
FR INB	23
FL PWM	3
FL INA	24
FL INB	25
RR PWM	4
RR INA	26
RR INB	27
RL PWM	5
RL INA	28
RL INB	29





Notes:


1. Assembly should be performed by knowledgeable and skilled individual. SuperDroid Robots offers assembly services if you are not comfortable reading schematics and performing work.
2. Wire gauges depend on load and size of motors.
3. Fuse size depends on load and size of motors.
4. Switch should be rated for at least the same amount of current as the fuse.
5. To charge batteries unplug them and use charger or run parallel wire with plug for charger.
6. Servo pigtail (TE-040-001) typically used. Receiver powered from motor controller (ensure motor controller rated for receiver).
7. If Battery is 12V you can connect the 2.1mm jack from the arduino to the 12V Bus.

RC Receiver
 Note In receiver connect:
 1. 0 v to pin 3, 6, 9 or 12.
 2. 5V to pin 2, 5, 8 or 11.


RC receiver Pin out

1	2	3
4	5	6
7	8	9
10	11	12

Drive pin A3
 Strafe pin A4
 Turn pin A5



Note: Spi in Arduino MEGA
 Miso 50
 Mosi 51
 SCK 52



Motor Encoder Pin Out
 Brown 5V
 Green Gnd
 Blue A
 Purple B
 Connect all 4 to the buffer board

